



FRESH AIR SENSOR TO SUIT HTC2 & 4 SERIES

SOT-H

The SOT-H is intended for external wall mounting to measure the outside air temperature, preferably located on a south facing wall, also avoid any reflected heat or influences from other heat sources. The SOT-H is suitable for use with Hevac HTC2 & 4 series controllers.



Made in Australia
100% Australian Owned Company

TEMP	OHMS	TEMP	OHMS	TEMP	OHMS	TEMP	OHMS
14.00	1834	18.00	1894	22.00	1954	26.00	2015
14.50	1842	18.50	1901	22.50	1962	26.50	2023
15.00	1849	19.00	1909	23.00	1969	27.00	2031
15.50	1856	19.50	1916	23.50	1977	27.50	2039
16.00	1864	20.00	1924	24.00	1985	28.00	2047
16.50	1871	20.50	1931	24.50	1992	28.50	2054
17.00	1879	21.00	1939	25.00	2000	29.00	2062
17.50	1886	21.50	1946	25.50	2008	29.50	2070

THIS CHART IS ONLY VALID WHEN **SENSOR SETPOINT** IS SET TO 22.0 oC

Environmental Conditions

Operation

Ambient Temperature	0...45oC
Humidity	< 95 % RH (Non Condensing)

Storage and Transport

Ambient Temperature	-5...65oC
Humidity	< 90 % RH (Non Condensing)

Product Standards

C-tick  N10842

Weight

Including Packaging 150 grams

Housing

Colour	Black
Material	ABS POLYCARB
UV Stabilised	YES
Fire Retardant	YES
Size	L130mm x W120mm x D35mm
Mounting Method	Wall mount 4 screw locations